




EXPLODED VIEW - OLD SERIE GAS-ON-GLASS HOB ASSEMBLY (BEFORE SEP-06)




EXPLODED VIEW - C SERIE GAS-ON-GLASS HOB ASSEMBLY (2006 - 2010)




EXPLODED VIEW - SERIE 2 GAS-ON-GLASS HOB ASSEMBLY (2010 - 2011)




EXPLODED VIEW - SERIE 2 (MODIFIED) GAS-ON-GLASS HOB ASSEMBLY (AFTER 2011)




COOKTOP BOTTOM COVER (GROUP,SECURIT)
(POSTION NO 407)



ETHNIC COFFEEPOTSUPPORT
(OPTIONAL)




WOK BURNER (OPTIONAL)




THERMOCOUPLE (OPTIONAL)


PAN SUPPORTS (OPTIONAL)




ENAMELLED
(GAS-ON-GLASS,SINGLE)



CAST IRON
(GAS-ON-GLASS,SLIM)




CAST IRON
(GAS-ON-GLASS,THICK)




MICRO SWITCH (OPTIONAL)


KNOBS (ONLY FOR HOB - OPTIONAL)




DELTA




ALFA




GAMA




ZETA




ECLIPSE




RUSTIC RISUS




BIG MEKA




SMALL MEKA
(ONLY FOR ELC /
DOMINO /
DOMINO -SERI2)



NORD



VESTA



JANNU

HOB ASSEMBLY PARTS

POSITION NUMBER	PART NAME
4	SCREW (KNURLED, 3.9*9.5)
58	GAS DELIVERY TUBE
30	TERMINAL BOX
31	POWER CORD
60	IGNITOR
63	MANIFOLD
64	STRAIGHT HOSE FITTING GASKET
66	COOKTOP VALVE
69	MICROSWITCH HARNESS
76	KNOB - GAS
83	COOKTOP VALVE ASSEMBLY BRACKET
84	COOKTOP VALVE ASSEMBLY BRACKET CONTACT SCREW
92	BURNER CAP (SEMI-RAPID / RAPID / AUXILARY/WOK BURNER)
93	BURNER HEAD (SEMI-RAPID / RAPID / AUXILARY/WOK BURNER)
95	PAN SUPPORTS
96	PAN SUPPORT BUMPER
98	SPARK PLUG GASKET
99	SPARK PLUG WITH CABLE
100	SPARK PLUG SEGMENT
101	THERMOCOUPLE
103	THERMOCOUPLE FIXING NUT
109	INJECTOR (SEMI-RAPID / RAPID / AUXILARY BURNER)
138	ETHNIC COFFEEPOT SUPPORT
160	IGNITOR BUTTON
167	KNOB GASKET
168	COOKTOP BOTTOM COVER (GAS)
182	VITROCERAMIC HOB BOTTOM COVER
183	HOB ASSEMBLY SPRING BRACKET
246	MANIFOLD ANGLE IRON 1/2"
257	WOK BURNER SUPPORT
269	GAS-ON GLASS ASSEMBLY
250	GAS-ON-GLASS HOB IGNITOR HOLDER
407	COOKTOP BOTTOM COVER (GROUP,SECURIT)
408	COOKTOP BURNER BRACKET(BOTTOM)
619	BURNER BODY

“The exploded view s given in this document are generic. They include all possible versions of the product. For specific part codes, please refer to the bom list of regarding model.”